



N4L **Newtons4th Ltd**

PPA3500

Communications Manual



This manual is copyright © 2006-2021 Newtons4th Ltd.
and all rights are reserved. No part may be copied or
reproduced in any form without prior written consent.

Document Title: PPA35xx Communications Manual v4.0

Document Release Date: 04th March 2021

PPA35xx Firmware version on release date: v2.49

Document Ref: D000222 issue 04

IMPORTANT SAFETY INSTRUCTIONS

This equipment is designed to comply with BSEN 61010-1 (2010) (Safety requirements for electrical equipment for measurement, control, and laboratory use) – observe the following precautions:

- Ensure that the supply voltage agrees with the rating of the instrument printed on the back panel **before** connecting the mains cord to the supply.
- This appliance **must** be earthed. Ensure that the instrument is powered from a properly grounded supply.
- The inputs are rated at 1kV rms or dc cat II; 600V rms or dc cat III. **Do not exceed the rated input.**
- Keep the ventilation slots in the top and sides of the cover free from obstruction.
- Do not operate or store under conditions where condensation may occur or where conducting debris may enter the case.
- There are no user serviceable parts inside the instrument – do not attempt to open the instrument, refer service to the manufacturer or his appointed agent.

Note: Newtons4th Ltd. shall not be liable for any consequential damages, losses, costs or expenses arising from the use or misuse of this product however caused.

ABOUT THIS MANUAL

This manual gives details of the communication commands recognized by the PPA35xx series of instruments over RS232, USB, or LAN. For more general operating instructions for the instrument refer to the specific user manual.

Each command is listed alphabetically with details of any arguments and reply. Although most of the commands apply to all instruments in the range there are some commands that are specific to one instrument or another.

The information in this manual is believed to be accurate and complete but Newtons4th Ltd cannot accept any liability whatsoever for any consequential damage or losses arising from any errors, inaccuracies, or omissions.

Notes:

The information in this manual is based on the 30A version of the PPA3560. There will be some minor differences to the Command options when using other PPA35xx models and current versions.

Unless otherwise stated Commands and Configs that control Group1 (PH1-PH3) will also control Group2 (PH4-PH6) when Group2 is the active group on the instrument.

CONTENTS

1	Using remote control	1-1
1.1	Standard event status register.....	1-3
1.2	Serial Poll status byte	1-4
1.3	RS232 connections.....	1-5
1.4	Data format	1-6
2	Communication commands	2-1
*CLS	2-1	
*ESE	2-2	
*ESR?.....	2-3	
*IDN?.....	2-4	
*OPC?	2-5	
*RST	2-6	
*SRE	2-7	
*SRE?.....	2-8	
*STB?.....	2-9	
*TRG	2-10	
*TST?.....	2-11	
*WAI	2-12	
ABORT.....	2-13	
ADIMAP	2-14	
ALARM.....	2-15	
ALARM?	2-16	
ALARM1	2-17	
ALARM2	2-18	
ALARME	2-19	
ALARME?.....	2-20	
ANALOG.....	2-21	
ANALOG?	2-22	
APPLIC.....	2-23	
BANDWI?	2-24	
BEEP	2-25	
BLANKI.....	2-26	
CALSTR?	2-27	
CALVER?	2-28	
CONFIG	2-29	
CONFIG?	2-30	
COUPLI.....	2-31	

PPA35xx communications manual

COUPLI?	2-32
DATALO	2-33
DATALO?	2-34
DAV?	2-35
DAVER	2-36
DAVER?	2-37
DISPLAY	2-38
DISPLAY?	2-39
EFFICI	2-40
EFFICI?	2-41
FAST	2-42
FQLOCK	2-43
FQREF	2-44
FREQUE	2-45
FSD?	2-46
GROUP	2-47
GROUP1	2-48
HARMON	2-49
HARMON?	2-50
HOLD	2-51
HPOWER	2-52
HPOWER?	2-53
INPUT	2-54
INTEGR	2-55
INTEGR?	2-56
KEYBOA	2-57
LCR	2-58
LCR?	2-59
LOWFRE	2-60
MODE	2-61
MULTIL	2-62
MULTIL?	2-63
NEWLOC	2-65
NOISEF	2-66
NOOVER	2-67
NORMAL	2-68
PFCNV	2-69
PHANGREF	2-70
PHASEM	2-71
PHASEM?	2-72
PHCONV	2-73
POWER	2-74
POWER?	2-75
PRIMAR	2-77

PPA35xx communications manual

PROGRA.....	2-78
PROGRA?	2-79
RANGE.....	2-80
RESOLU	2-81
RESULT.....	2-82
RESULT?	2-83
REZERO	2-84
SCALE	2-85
SCOPE?	2-86
SCREEN?.....	2-87
SHUNT.....	2-88
SMOOTH	2-89
SPEED	2-90
START	2-91
STATUS?.....	2-92
STOP	2-93
SUSPEN	2-94
TAGREP	2-95
TORQSP.....	2-96
TORQSP?	2-97
USER?	2-98
VARCON	2-99
VERSIO?	2-100
VRMS	2-101
VRMS?.....	2-102
WIRING	2-103
XSCALE	2-104
ZERO.....	2-106
ZOOM.....	2-107
ZOOM?	2-108
3 Multilog Application Guide.....	3-1

Appendix A – configurable parameters

Appendix B – MULTIL parameters

1 Using remote control

The instrument is fitted with an RS232 serial communications port and USB interface as standard, and may have a LAN interface fitted as an option. All the interfaces use the same ASCII protocol:

	Rx expects	Tx sends
RS232 USB, LAN	carriage return (line feed ignored)	carriage return and line feed

All the functions of the instrument can be programmed via any interface, and results read back.

The commands are not case sensitive and white space characters are ignored (e.g. tabs and spaces). Replies from the instrument are always upper case, delimited by commas, without spaces.

Only the first six characters of any command are important – any further characters will be ignored. For example, the command to set the generator frequency is FREQUE but the full word FREQUENCY may be sent as the redundant NCY at the end will be ignored.

Fields within a command are delimited by comma, multiple commands can be sent on one line delimited with a semi-colon. Eg.

FQREF,CURRENT;POWER?

Mandatory commands specified in the IEEE488.2 protocol have been implemented, (e.g. *IDN?, *RST) and all commands that expect a reply are terminated with a question mark (query).

The instrument maintains an error status byte consistent with the requirements of the IEEE488.2 protocol (called

the standard event status register) that can be read by the mandatory command *ESR? (see section 2).

The instrument also maintains a status byte consistent with the requirements of the IEEE488.2 protocol, that can be read either with the IEEE488 serial poll function or by the mandatory command *STB? over RS232 or LAN (see section 2).

RS232 data format is: start bit, 8 data bits (no parity), 1 stop bit. Flow control is RTS/CTS (see section 1.3), baud rate is selectable via the MONITOR menu.

A summary of the available commands is given in the Appendix. Details of each command are given in the communication command section of the manual.

Commands are executed in sequence except for two special characters that are immediately obeyed:

- Control T (20) – reset interface (device clear)
- Control U (21) – warm restart

1.1 Standard event status register

PON		CME	EXE	DDE	QYE		OPC
-----	--	-----	-----	-----	-----	--	-----

- bit 0 OPC (operation complete)
cleared by most commands
set when data available or sweep complete
- bit 2 QYE (unterminated query error)
set if no message ready when data read
- bit 3 DDE (device dependent error)
set when the instrument has an error
- bit 4 EXE (execution error)
set when the command cannot be executed
- bit 5 CME (command interpretation error)
set when a command has not been recognised
- bit 7 PON (power on event)
set when power first applied or unit has reset

The bits in the standard event status register except for OPC are set by the relevant event and cleared by specific command (*ESR?, *CLS, *RST). OPC is also cleared by most commands that change any part of the configuration of the instrument (such as MODE or START).

1.2 Serial Poll status byte

		ESB	MAV	ALA			RDV
--	--	-----	-----	-----	--	--	-----

- bit 0 RDV (result data available)
set when results are available to be read as enabled by DAVER
- bit 3 ALA (alarm active)
set when an alarm is active and enabled by ALARMER
- bit 4 MAV (message available)
set when a message reply is waiting to be read
- bit 5 ESB (standard event summary bit)
set if any bit in the standard event status register is set as well as the corresponding bit in the standard event status enable register (set by *ESE).

1.3 RS232 connections

The RS232 port on the instrument uses the same pinout as a standard 9 pin serial port on a PC or laptop (9-pin male 'D' type).

Pin	Function	Direction
1	DCD	in (+ weak pull up)
2	RX data	in
3	TX data	out
4	DTR	out
5	GND	
6	DSR	not used
7	RTS	out
8	CTS	in
9	RI	not used

The instrument will only transmit when CTS (pin 8) is asserted, and can only receive if DCD (pin 1) is asserted. The instrument constantly asserts DTR (pin 4) so this pin can be connected to any unwanted modem control inputs to force operation without handshaking. The instrument has a weak pull up on pin 1 as many null modem cables leave it open circuit. In electrically noisy environments, this pin should be driven or connected to pin 4.

To connect the instrument to a PC, use a 9 pin female to 9 pin female null modem cable:

1 & 6	-	4
2	-	3
3	-	2
4	-	1 & 6
5	-	5
7	-	8
8	-	7

1.4 Data format

Non integer results are sent as ASCII characters in a scientific format consisting of 5 or 6 digit mantissa plus exponent:

+1.2345+E00
+1.23456+E00

For higher speed transfer a proprietary binary format can be selected which compresses the data into 4 bytes, each of which is sent with the msb set to distinguish them from ASCII control characters. The data is sent as a 7 bit signed exponent, a mantissa sign, and a 20 bit mantissa:

byte	data
1	7 bit signed exponent +63 to -64
2	bit 6 = mantissa sign bit 5:0 = mantissa bit 19:14
3	mantissa bit 13:7
4	mantissa bit 6:0

The value is coded as a binary fraction between 0.5 and 0.9999..., a multiplier of 2^n and a sign ie:

$$\text{Value} = (\text{mantissa} / 2^{20}) \times 2^{\text{exponent}} \times -1^{\text{sign}}$$

value	equivalent	hex data transmitted
3.0	0.75×2^2	0x82,0xB0,0x80,0x80
0.1	0.8×2^{-3}	0xFD,0xB3,0x99,0xCD
-320	-0.625×2^9	0x89,0xE8,0x80,0x80

Any valid number would have the msb of the mantissa set; any number without the msb of the mantissa set is zero.

2 Communication commands

***CLS**

***CLS**

Function: Clear status

Description: Clears the *standard event status register*.

Format: *CLS

Arguments: none

Reply: none

Example:
*CLS
*ESR?
0

Notes:

ESE**ESE**

Function:	Set standard event status enable register.
Description:	Enable which bits of the <i>standard event status register</i> set the ESB bit in the serial poll status byte..
Format:	*ESE, value
Arguments:	decimal equivalent of bits in standard event status enable register
Reply:	can be read by *ESE?
Example:	*ESE, 60
Notes:	The following bits in the standard event status enable register have been implemented: bit 0 OPC (operation complete) bit 2 QYE (unterminated query error) bit 3 DDE (device dependent error) bit 4 EXE (execution error) bit 5 CME (command interpretation error) bit 7 PON (power on event)

For example, *ESE, 60 enables all the error bits so that the ESB bit in the serial poll status byte is set in the event of any error.

ESR?**ESR?**

Function:	Standard event status register query
Description:	Returns the contents of the <i>standard event status register</i> and clears it.
Format:	*ESR?
Arguments:	none
Reply:	decimal equivalent of bits in standard event status register
Example:	*ESR? 33
Notes:	The following bits in the standard event status register have been implemented: <ul style="list-style-type: none">bit 0 OPC (operation complete)bit 2 QYE (unterminated query error)bit 3 DDE (device dependent error)bit 4 EXE (execution error)bit 5 CME (command interpretation error)bit 7 PON (power on event)

For example, if a command is sent incorrectly and is not recognised, the CME bit will be set and the value of 33 will be returned.

PPA35xx communications manual

***IDN?**

***IDN?**

Function: Identify query

Description: Returns a standard format identification string.

Format: *IDN?

Arguments: none

Reply: An ASCII string in the IEEE488.2 format:
manufacturer,model,serial no,version

Example: *IDN?
NEWTONS4TH,PPA3530 KinetiQ,
196-01234,1.00

Notes:

OPC?**OPC?**

Function:	Test for operation complete
Description:	Returns 1 if previous operation is completed, 0 if not.
Format:	*OPC?
Arguments:	none
Reply:	0 or 1
Example:	START *OPC? 0 *OPC? 0 *OPC? 1
Notes:	*OPC? can be used to indicate when data is available or when a frequency sweep has completed.

RST**RST**

Function: Reset

Description: Resets the instrument to the default state and clears the *standard event status register*.

Format: *RST

Arguments: none

Reply: none

Example: *RST

Notes: The *RST command loads the default configuration. This is the same as loading the default configuration via the PROGRAM menu.

Any preceding setup commands will be overwritten.

SRE**SRE**

Function: Set service request enable register.

Description: Enable which bits of the *status byte register* initiate a service request.

Format: *SRE, value

Arguments: decimal equivalent of bits in status byte register

Reply: can be read by *SRE?

Example: *SRE, 1
generate a service request when data available.

Notes:

SRE?**SRE?**

Function: Read service request enable register.

Description: Read back the present setting of the service request enable register.

Format: *SRE?

Arguments:

Reply: decimal equivalent of bits in status byte register that would generate a service request.

Example: *SRE?
1

Notes:

STB?**STB?**

Function:	Read serial poll status byte
Description:	Returns the decimal value of the serial poll status byte.
Format:	*STB?
Arguments:	none
Reply:	decimal value of the serial poll status byte
Example:	*STB? 1
Notes:	The following bits in the serial poll status register have been implemented: bit 0 RDV (results data available) bit 3 ALA (alarm active) bit 4 MAV (message available) bit 5 ESB (standard event summary bit)

TRG**TRG**

Function: Trigger

Description: Initiates a new measurement, resets the range and smoothing.

Format: *TRG

Arguments: none

Reply: none

Example:
MODE,VRMS
*TRG
VRMS,SURG?

Notes:

TST?**TST?**

Function:	Self test query
Description:	Returns the results of self test
Format:	*TST?
Arguments:	none
Reply:	single integer bit 0 – set if uncalibrated bit 1 – set if DSP zero error bit 2 – set if DSP run error bit 3 – not used bit 4 – System error, FPGA bit 5 – System error, DSP RAM bit 6 – System error, DSP run bit 7 – System error, external RAM bits 8 – 14 not used > 15 – major system
Example:	*TST? 0
Notes:	

WAI**WAI**

Function: Wait for operation complete

Description: Suspends communication until the previous operation has completed

Format: *WAI

Arguments: none

Reply: none

Example:
*TRG
*WAI
POWER,PHASE1?

Notes:

ABORT

ABORT

Function: Abort datalog

Description: Abort datalog data acquisition.

Format: ABORT

Arguments: none

Reply: none

Example: DATALOG, RAM, 0.02
START
wait for data values
ABORT

Notes:

Function: Map multilog parameters to outputs.

Description: Applies offset and scaling to a multilog value and maps value to chosen ADI output.

Format: ADIMAP,output,multilog,offset,scale

Arguments:

- output: 1-20
- Multilog: 1-64
- offset: Float
- scale: Float

Reply: none

Example:

- MULTIL,0
- MULTIL,2,1,1 (PH1 Frequency)
- ADIMAP,1,2,0.2,0.5

Output 1 = 0.5 * (PH1 frequency – 0.2)

Notes: Offset is subtracted from multilog value, then scale is applied within the limits of +/- 10

ALARM**ALARM**

Function: Set common controls for alarm1 and alarm2.

Description: Set the alarm latch and sounder control.

Format: ALARM,*latch,sounder*

Arguments:

- latch:
 - ON
 - OFF
- sounder:
 - ENABLED
 - DISABLED

Reply: none

Example: ALARM,ON,DISABLED

Notes:

ALARM?

ALARM?

Function: Read alarm status.

Description: Reads the status of the measurements and 2 alarms.

Format: ALARM?

Arguments: none

Reply: single integer
bit 0 data available
bit 1 data error
bit 2 alarm 1
bit 3 alarm 2

Example: ALARM?
1

Notes: An alarm is present if bit 0 is high (data is available) and either alarm 1 or alarm 2 bits are high.

ALARM1**ALARM1**

Function: Set parameters for alarm1.

Description: Set alarm1 type and thresholds.

Format: *ALARM1,type,data,high,low*

Arguments:

- type:
 - DISABLED
 - HIGH
 - LOW
 - INSIDE
 - OUTSIDE
 - LINEAR
- data
 - 1-4
- high:
 - high threshold
- low:
 - low threshold

Reply: none

Example: ALARM1,HIGH,1,2,0

Notes: Both thresholds must be sent even if only one is used.

ALARM2**ALARM2**

Function: Set parameters for alarm2.

Description: Set alarm2 type and thresholds.

Format: *ALARM2,type,data,high,low*

Arguments:

- type:
 - DISABLED
 - HIGH
 - LOW
 - INSIDE
 - OUTSIDE
- data
 - 1-4 for zoom data
- high:
 - high threshold
- low:
 - low threshold

Reply: None

Example: ALARM2,LOW,3,0,0.5

Notes: Both thresholds must be sent even if only one is used.
There is no LINEAR option for alarm 2.

ALARME**ALARME**

Function: Set alarm status enable register

Description: Sets bits in the alarm status enable register to control which alarm bit if any set the alarm active bits in the status byte.

Format: ALARME,*value*

Arguments: decimal equivalent of alarm bits
bit2 set bit 3 of status byte when
alarm 1 is active
bit3 set bit 3 of status byte when
alarm 2 is active

Reply: none

Example: ALARME, 12
*SRE,8
set bit 3 in status byte when either alarm
1 or alarm 2 is active and generate a
service request

Notes: default value is 0

ALARME?

ALARME?

Function: Read alarm status enable register

Description: Read back present bits in the alarm status enable register which controls the alarm active bit in the status byte.

Format: ALARME?

Arguments: none

Reply: decimal equivalent of alarm bits

Example: ALARME?
12

Notes:

ANALOG**ANALOG**

Function: Interface with ADI40

Description: Write to individual ADI40 outputs

Format: ANALOG,channel,value

Arguments:

- Channel:
1-20
- Value:
-10.00 to +10.00

Reply: None

Example: ANALOG,5,-3.14

Notes: Up to 9 outputs can be written to with one CommView transfer, by separating each instance with a ";".

ANALOG?

ANALOG?

Function: Interface with ADI40

Description: Read from individual ADI40 inputs.

Format: ANALOG,channel?

Arguments: Channel:
 1-20

Reply: ASCII characters in scientific format:
 1 - 16 in Volts
 17- 20 in °C None

Example: ANALOG,12?

Notes: Up to 9 inputs can be read back at once
 with this command by separating each
 instance with a ";".

APPLIC**APPLIC**

Function: Select application mode.

Description: Some applications require special settings within the instrument for optimum measurement

Format: *APPLIC,type,setting*

Arguments:

- type:
 - NORMAL
 - PWM
 - BALLAST
 - INRUSH
 - POWERT
 - STANDB
- setting:
 - filter 0-6 (PWM only)
 - 0: 4KHz
 - 1: 1KHz
 - 2: 250Hz
 - 3: 64Hz
 - 4: 250KHz
 - 5: 64KHz
 - 6: 16KHz
 - speed 0-3 (ballast only)
 - 0: fixed time
 - 1: fast
 - 2: medium
 - 3: slow

Reply: none

Example: APPLIC,POWERT
APPLIC,BALLAST,1

Notes:

BANDWI?

BANDWI?

Function: Selects the hardware bandwidth filter

Description: The bandwidth may be set to "wide" or "low" to minimise high frequency noise in noisy environments.

Format: *BANDWI,setting*

Arguments: Setting:
LOW
WIDE

Reply: None

Example: BANDWI,LOW

Notes:

BEEP

BEEP

Function: Sound the buzzer

Description: Makes a “beep” from the instrument.

Format: BEEP

Arguments: none

Reply: none

Example: BEEP

Notes:

BLANKI**BLANKI**

Function: Select blanking

Description: Enable or disable low value blanking.

Format: BLANKI,*value*Arguments: *value*:

ON

OFF

Reply: none

Example: BLANKI,OFF

Notes:

CALSTR?**CALSTR?**

Function: Read back the N4L last calibration string.

Description: When calibrated at N4L, the instrument stores a text string which can be read on the front panel (press SYS and LEFT to display the System menu and refer to N4L Last Calibration). This shows the date of calibration. Users who subsequently verify the accuracy using a local calibration facility can choose have details of the local calibration displayed instead. The original N4L string is not overwritten but the alternative local calibration string is displayed instead.

Format: CALSTR?

Arguments: none

Reply: alphanumeric string

Example: CALSTR?
12_AUG_2020_1055_AMW

Notes: CALSTR? Will read back the most recent N4L last calibration string including on instruments that are displaying details of a more recent local calibration.

CALVER?**CALVER?**

Function: Read back the Local calibration string.

Description: When calibrated using an external calibration facility details of the calibration can be stored on the instrument. This text string can be read on the front panel (press SYS and LEFT to display the System menu and refer to Local Calibration). This shows the date of the local calibration. The original N4L string is not overwritten but the alternative local calibration string is displayed instead.

Format: CALVER?

Arguments: none.

Reply: alphanumeric string

Example: CALVER?
12_AUG_2020_1055_AMW

Notes: CALVER? Will read back the most recent local calibration string. The string will be blank if no local calibration has been performed or no information was entered when the local calibration was performed.

CONFIG**CONFIG**

Function: Direct access of configuration parameters

Description: Sets configuration parameter for which there may not be a direct command.

Format: *CONFIG,index,data*

Arguments: index is the number of the parameter
data is the data for that parameter

Reply: none

Example: CONFIG,6,1 (set phase convention)

Notes: The list of configurable parameters is given in the appendix.
CONFIG goes through the same limit checking as when entering data from the menus.

CONFIG? **CONFIG?**

Function: Configurable parameter query

Description: Reads the present value of a single parameter.

Format: `CONFIG,index?`
or: `CONFIG?index`

Arguments: *index* is the parameter number

Reply: Value of parameter, real or integer as appropriate.

Example: `CONFIG,6? (read phase convention)`
 0
 `CONFIG,6,1 (set phase convention)`
 `CONFIG,6?`
 1

Notes: The list of configurable parameters is given in the appendix.

COUPLI**COUPLI**

Function: Set ac, dc or ac+dc coupling.

Description: Selects the input coupling for a given input channel.

Format: COUPLI,*phase,coupling*

Arguments:

- phase:
 - PHASE1
 - PHASE2
 - PHASE3
 - PHASE4
 - PHASE5
 - PHASE6
- coupling:*
 - AC+DC
 - ACONLY
 - DCONLY

Reply: none

Example: COUPLI,PHASE2,AC+DC

Notes: In multi phase applications, the coupling on phase 1 is applied to other phases unless "independent input control" is enabled. For example when WIRING > SINGLE PHASE 2 is selected.
PHASE4-6 may also be set by using PHASE1-3 when group 2 is the active group.

COUPLI?**COUPLI?**

Function: Read ac/dc/ac+dc coupling setting.

Description: Returns a numerical value for the coupling setting.

Format: COUPLI,*phase,coupling?*
or: COUPLI?*phase,coupling*

Arguments: phase:
PHASE1
PHASE2
PHASE3
PHASE4
PHASE5
PHASE6

Reply: 0 = AC+DC
1 = ACONLY
2 = DCONLY

Example: COUPLI,PHASE2,AC+DC
COUPLI,PHASE2?
0

Notes: In multi phase applications, the coupling on phase 1 is applied to other phases unless "independent input control" is enabled. For example when WIRING > SINGLE PHASE 2 is selected.

DATALO**DATALO**

Function: Set up datalog

Description: Sets datalog parameters.

Format: **DATALO**,*function,interval,speed*

Arguments:

- function:*
 - DISABLE
 - RAM
 - NONVOL
 - RECALL
 - DELETE
- interval:*
 - datalog interval in seconds
- speed:*
 - HIGH

Reply: none

Example: DATALO, RAM, 10
DATALO, RAM, 0, HIGH

Notes: set interval to 0 to record every measurement as fast as possible.
Set HIGH to select high speed mode for any combination of W, VA, VAr, pf, Vrms, Arms, and frequency. If HIGH is not sent then high speed mode is reset.

DATALO? **DATALO?**

Function:	Read back datalog results
Description:	Return datalog values, one record per line, or the number of lines available
Format:	DATALO, <i>start,records?</i> DATALO,0? DATALO,LINES?
Arguments:	start: first record to return records: number of records to return 0: return all new records since last read
Reply:	3 to 6 data values depending on settings: index 1-n elapsed time in hours data1 data2 (if stored) data3 (if stored) data4 (if stored) one record per line
Example:	DATALO,RAM,10 START wait for datalog STOP DATALO,LINES? 30 DATALO,21,3? 21,2.0000E-1,1.2345E0 22,2.1000E-1,5.6789E3 23,2.2000E-1,1.2345E0
Notes:	if no arguments are sent then DATALO? returns all the available lines of data

PPA35xx communications manual

DAV? **DAV?**

Function: Data available query
Description: Returns data availability status.
Format: DAV?
Arguments: none
Reply: Decimal equivalent of data available bits:
bit0 new data available
bit1 data available
bit2 harmonic series data available
bit6 integration data available
bit7 datalog data available
Example: SPEED,SLOW
*TRG
DAV?
0
DAV?
0
DAV?
0
DAV?
3 (data available)
Notes: DAV? does not modify the status bits.

Function: Set data available enable register

Description: Sets bits in the data available enable register to control which status bits set the data available bits in the status byte.

Format: DAVER,*value*

Arguments: decimal equivalent of data available bits
bit0 set bit 0 of status byte when new data available
bit1 set bit 0 of status byte when data available

Reply: none

Example: DAVER, 1
set bit 0 in status byte when new data is available

Notes: default value is 2:
bit 0 of status byte is set whenever data is available.

DAVER?**DAVER?**

Function: Read data available enable register

Description: Read back present setting of the data available enable register, which controls the status bits that set the data available bits in the status byte.

Format: DAVER?

Arguments: none

Reply: decimal equivalent of bits

Example: DAVER?
4

Notes:

DISPLAY **DISPLAY**

Function: Set the display page

Description: Selects the page on the display for the active group.

Format: *DISPLAY,page*

Arguments: *page:*

- PHASE1
- PHASE2
- PHASE3
- SUM1
- NEUTRAL1
- TOTAL
- FUNDAMENTAL
- VOLTAGE
- CURRENT

Reply: None

Example: *DISPLAY,FUNDAMENTAL*

Notes: VOLTAGE is the same as TOTAL;
CURRENT is the same as FUNDAMENTAL.
They refer to the multiphase display modes.

If Group 2 is the active group then the above applied to Group 2 (PH4-PH6).

DISPLAY?

DISPLAY?

Function: Read the displayed data
Description: Returns all the values presently on the screen for the active group.
Format: DISPLAY?
Arguments: none
Reply: Multiple floating point values separated by commas
Example: DISPLAY?
Notes:

EFFICI**EFFICI**

Function: Set efficiency calculation

Description: Selects the data to be used for the efficiency calculation for the active group.

Format: *EFFICI,formula*

Arguments: formula:
0 – disabled
1 – next phase / phase
2 – phase / next phase
3 – group 2 / group 1
4 – group 1 / group 2
5 – mechanical / sum
6 – sum / mechanical
7 – phase 3 / sum
8 – sum /phase 3

Reply: none

Example: EFFICIENCY,3

Notes:

EFFICI?**EFFICI?**

Function: Read efficiency result

Description: Reads back the total and fundamental efficiency results.

Format: EFFICI?

Arguments: none

Reply: 2 data values separated by commas:
total, fundamental
or 6 data values

Example: EFFICI?
data returned

Notes: 6 data values returned if efficiency option
is phase / next phase and 3 phase wiring
is configured

FAST

FAST

Function: Set fast communications mode.

Description: Disables the screen drawing for high speed operation.

Format: **FAST**,*value*

Arguments: *value*:

ON

OFF

Reply: none

Example: **FAST,ON**

Notes: FAST mode does not suppress the data acquisition which continues in the background. See SUSPEND to disable all non-communication functions.

FQLOCK**FQLOCK**

Function: Lock frequency.

Description: Fix the frequency for analysis to the present value.

Format: FQLOCK,*mode,frequency*

Arguments: value:
 ON
 OFF
 NORMAL
 CONSTANT [,frequency]
 DYNAMIC

Reply: none

Example: FQLOCK,ON

Notes: OFF is the same as NORMAL
To fix the analysis to a specified frequency, either first lock the frequency with FQLOCK,ON and send the desired frequency with the FREQUE command or send CONSTANT followed by the frequency.

FQREF**FQREF**

Function: Set frequency reference.

Description: Select the channel to be used for measuring the frequency on the active group.

Format: FQREF,*phase*
FQREF,*channel*
FQREF,*phase,channel*

Arguments:

channel:	voltage
	current

phase:	PHASE1
	PHASE2
	PHASE3

Reply: none

Example: FQREF,CURRENT

Notes: Measured phase is always referred to phase 1 voltage no matter what channel is selected to measure the frequency, unless phase 1 is not active (eg phase 2 only mode).

FREQUE **FREQUE**

Function: Set the analysis frequency

Description: Sets the analysis frequency in Hz for frequency lock mode.

Format: FREQUE,*frequency*

Arguments: *frequency* in Hz

Reply: none

Example: FQLOCK,ON
FREQUE,5e4 (set frequency to 50kHz)

Notes: Lock the frequency with FQLOCK,ON before sending the desired frequency with the FREQUE command.

FSD? **FSD?**

Function:	Read the full scale of all input channels at once or that of an individually selected input channel.
Description:	Returns the full scale value for all channels or that of a single selected channel.
Format:	FSD? FSD, <i>channel</i>
Arguments:	Channel: CH1 CH2 CH3 CH4 CH5 CH6
Reply:	Up to six data values separated by commas
Example:	FSD,CH1? Data returned
Notes:	Number of channels that can be read and the number of data values returned is dependent on the number of phases selected in the instruments settings. CH1 = PH1: Voltage Input CH2 = PH1: Current Input CH3 = PH2: Voltage Input CH4 = PH2: Current Input CH5 = PH3: Voltage Input CH6 = PH3: Current Input

GROUP

GROUP

Function: Set the active group.

Description: Select the group to which all future commands will be directed.

Format: GROUP,*group*

Arguments: group:
 1 or 2

Reply: none

Example: GROUP,2

Notes:

GROUP1**GROUP1**

Function: Set the number of phases in group 1.

Description: If there are more than three phases in group 1 then the instrument will operate in single group mode, otherwise the instrument will operate with two independent groups. A six phase unit always has at least three phases in group 1; a four phase unit could have one to four phases in group1

Format: GROUP1,*phases*

Arguments: *phases:*
1 to 6

Reply: none

Example: GROUP1,6

Notes: For a four phase unit, set group 1 to
1 for 1 : 2+3+4
2 for 1+2 : 3+4
3 for 1+2+3 : 4
4 for 1+2+3+4 (single group)

For a six phase unit set group 1 to
1 for 1+2+3 : 1+2+3
3 for 1+2+3 : 4+5+6
4 for 1+2+3+4
5 for 1+2+3+4+5
6 for 1+2+3+4+5+6

HARMON**HARMON**

Function: Set harmonic analyser mode.

Description: Set harmonic analyser mode and parameters.

Format: HARMON,*para*,*harmonic*,*max*

Arguments:

para:	THDD difference formula THD
	THDS harmonic series THD
	TIF Telephone Influence Factor
	THF Telephone Harmonic Factor
	TDD Total Demand Distortion
	TRD Total Rated Distortion
	HPHASE harmonic phase
	HRMS harmonic rms
	HFACTO harmonic factor
	PH-PH phase to phase

harmonic:
individual harmonic for display

max:
length of harmonic series (to 50)

Reply: none

Example: HARMON,THDS,3,50

Notes: It is not necessary to send any arguments, but if any are sent they must be in the specified order.

PH-PH sets the conversion from normal to PH-PH measurement (Harmonic menu options).

HARMON?**HARMON?**

Function: Harmonic analyser query

Description: Read harmonic results.
 Sets harmonic analyser mode if not already set.
 Waits for next unread data if necessary.
 Clears new data available bit read by DAV?

Format: HARMON?
 or: HARMON,*phase*?
 or: HARMON,SERIES?
 or: HARMON,*phase*,SERIES?

Arguments: *phase*:
 PHASE1
 PHASE2
 PHASE3
 PHASE4
 PHASE5
 PHASE6
 NEUTRAL
 PHASES

Reply: 11 data values separated by commas:
 freq,mag1,mag2,hmag1,hmag2,h%1,
 h%2,thd%1,thd%2,hphase1,hphase2
 or: magnitude and percentage for each harmonic, one channel per line
 or: magnitude and phase for each harmonic, one channel per line

Example: HARMON,PHASE2?
 data returned

Notes: HARMON? waits for next unread data.

HOLD**HOLD**

Function: Set data hold

Description: Turns data hold on or off. Useful for reading data from different phases without it being changed between reads.

Format: HOLD,state

Arguments: state:
 ON
 OFF

Reply: none

Example: HOLD,ON
 POWER,PHASE1,WATTS?
 POWER,PHASE2,WATTS?
 POWER,PHASE3,WATTS?
 HOLD,OFF

Notes: Turns data hold on or off for group 1 and group 2 at the same time.

HPOWER**HPOWER**

Function: Set harmonic power parameters

Description: Sets power parameters but does not change to power mode so that power can be measured in harmonic series mode.

Format: See POWER

Arguments: See POWER

Reply: none

Example: See POWER

Notes:

HPOWER?

HPOWER?

Function: Read harmonic power results
Description: Reads power results but does not change
 to power mode so that power can be read
 in harmonic series mode.
Format: See POWER?
Arguments: See POWER?
Reply: None
Example: See POWER?
Notes:

INPUT **INPUT**

Function: Set input mode
Description: Selects the input type of the instrument
Format: INPUT,*channel,type*
Arguments: channel:
 CH1
 CH2
 CH3
 CH4
 CH5
 CH6
 type:
 INTERN
 EXTATT
 EXTSHU

Reply: None
Example: INPUT,CH1,EXTSHU
Notes: CH1 applies to all voltage channels
 (unless in single phase 2 or 3 wiring)
 CH2 applies to all current channels
 (unless in single phase 2 or 3 wiring)
 CH3 and 4 apply to phase 2 voltage and
 current when in single phase 2 wiring
 CH5 and 6 apply to phase 3 voltage and
 current when in single phase 3 wiring

INTEGR**INTEGR**

Function: Set integrated power mode.

Description: Set integrated power mode, whether the integration for Watts and current use signed or unsigned values, and whether accumulated or averaged values are computed.
Also sets up run time for integration over a specific interval.

Format: *INTEGR,type,display*
INTEGR,RUNTIM,hours,minutes

Arguments:

- type:
 - SIGNED
 - MAGNITUDE
- display:
 - TOTAL
 - AVERAGE
- hours:
 - integer
- minutes:
 - integer

Reply: none

Example: INTEGR,MAGNITUDE,TOTAL

Notes:

INTEGR? **INTEGR?**

Function: Read integrated power mode.

Description: Read integrated power mode for the selected phase.

Format: INTEGR,*phase*?

Arguments: *phase*:

- PHASE1
- PHASE2
- PHASE3
- PHASE4
- PHASE5
- PHASE6
- PHASES
- SUM

Reply: 13 values separated by commas
time,Wh,WH.f,VAh,VAh.f,VArh,Varh.f
pf,pf.f,V,V.f,Ah,Ah.f

Example: START
wait for integration time
INTEGR,PHASE1?
data returned

Notes: INTEGR? without specifying the phase returns the appropriate single phase data.

KEYBOA**KEYBOA**

Function: Disable front panel keyboard.

Description: The front panel keyboard can be disabled to prevent accidental operation.

Format: KEYBOARD,*value*

Arguments:

value:	ENABLE
	DISABLE

Reply: none

Example: KEYBOARD,DISABLE

Notes: The keyboard can be re-enabled from the front panel only by pressing the HOME key.

LCR**LCR**

Function: Set Impedance meter (LCR) mode.

Description: Set Impedance meter (LCR) mode and conditions.

Format: LCR,*parameter*

Arguments: *parameter*:

- AUTO
- CAPACITANCE
- INDUCTANCE
- IMPEDANCE

Reply: none

Example: LCR,CAPACI
LCR,INDUCT
LCR,IMPEDA

Notes:

LCR?**LCR?**

Function:	Impedance meter (LCR) query
Description:	Read Impedance meter (LC meter results. Sets LCR meter mode if not already set. Waits for next unread data if necessary. Clears new data available bit read by DAV?
Format:	LCR, <i>phase</i> ?
Arguments:	<i>phase</i> : PHASE1 PHASE2 PHASE3 PHASE4 PHASE5 PHASE6 PHASES
Reply:	11 data values separated by commas: freq, Vmag, Amag, impedance, phase, R, C, L, tanδ, Qf, reactance Phases? returns 11 data values for each phase.
Example:	LCR,IMPEDA LCR,PHASES? data returned
Notes:	LCR? waits for next unread data. LCR? without specifying the phase returns the appropriate single phase data.

LOWFRE**LOWFRE**

Function: Set low frequency mode

Description: Sets the low frequency option for extending the measurement window.

Format: LOWFRE,*value*

Arguments: *value*:

ON

OFF

Reply: none

Example: LOWFRE,ON

Notes: LOWFRE is mainly used for measuring low frequencies (<5 Hz). However, as it applies digital filtering, it may also be useful when analysing any signals below a few hundred Hertz.

MODE **MODE**

Function: Set mode

Description: Sets the basic operating mode of the instrument.

Format: MODE,*type*

Arguments: type:

POWER (power meter)
INTEGR (integrator)
HARMON (harmonic analyser)
RMS (rms voltmeter)
LCR (Impedance [LCR] meter)
SCOPE (oscilloscope)
PHASEM (phase meter)

Reply: none

Example: MODE,LCR

Notes:

MULTIL**MULTIL**

Function: Selects data for multi string reply

Description: Selects data values across phases and functions that can be read in a single string.

Format: *MULTIL,index,phase,function*

Arguments:

index:	0	clear all
	1-30	select data 1-30
phase:	1-3	phase 1-3
	4	sum
	5	neutral
	6	ADI40
	7-9	phase 4-6
	10	sum 2
	11	neutral 2
function:	1-99	see appendix

Reply: none

Example:

MULTIL,0	
MULTIL,1,1,2	(phase 1 Watts)
MULTIL,2,2,2	(phase 2 watts)
MULTIL,3,4,3	(sum VA)
MULTIL?	
	3 data values returned

Notes:

MULTIL?**MULTIL?**

Function:	Reads multi string reply
Description:	Waits for data to be available (if required) then returns selected results. Either a single string or multiple string replies can be selected.
Format:	MULTIL? MULTIL,number?
Arguments:	number: The required number of data string replies
Reply:	A single reply string containing up to 64 data values as selected by the MULTIL command. Multiple reply strings each containing the same number of data values (maximum of 64) as selected by the MULTIL command.
Example:	MULTIL,0 MULTIL,1,1,2 (phase 1 Watts) MULTIL,2,2,2 (phase 2 watts) MULTIL,3,4,3 (sum VA) MULTIL? MULTIL? In the above example a single string reply containing 3 data values is returned. MULTIL,10? In the above example 10 data strings are returned, each string containing 3 data values.

PPA35xx communications manual

Notes: The `MULTILOG,number?` command will reply each time a new data point is available.

For further information and assistance with the Multilog application please go to page 3-1 where you will find an application guide to assist with this function

NEWLOC**NEWLOC**

Function: Waits for new data then holds so that multiple commands can be used on the same data set.

Description: Reads multiple sets of data

Format: NEWLOC

Arguments: None

Reply: Data as per returned parameter query. ie from power, harmonics etc.

Example:

```
NEWLOC  
HARMON,SERIES?  
HPOWER?  
Harmonic series and Power data returned  
from the same data.
```

Notes: After the command the data will still be held so to release the lock send SUSPEND,OFF

NOISEF**NOISEF**

Function: Set the digital noise filter

Description: Select the noise filter and set the filter frequency to reduce the presence of high frequency noise.

Format: NOISEF,*setting,frequency*

Arguments:

- setting:
 - ON
 - OFF
- Frequency:
 - Frequency in Hz

Reply: none

Example: NOISEF,ON,150E3

Notes: Minimum filter frequency is 1kHz.
Because the same digital filter is applied to voltage and current there is no introduced phase error.

NOOVER**NOOVER**

Function:	Disable overranging
Description:	Prevents an overrange error from blanking out results in manual ranging.
Format:	NOOVER, <i>value</i>
Arguments:	<i>value</i> : ON OFF
Reply:	none
Example:	NOOVER,ON
Notes:	This can be useful when testing devices in a noisy environment. The range can be set to the correct range for the signal to be measured even if sporadic noise spikes would push it up on to the next range. On the instrument this command adjusts Ignore Overload and can be found in the ACQU > Advanced Options menu.

NORMAL**NORMAL**

Function: Sets the Normalise reference to Current or Voltage.

Description: Sets the Reference for the NORMALISE function. Press ZERO on the instrument to action the function.

Format: NORMAL,reference

Arguments: Reference:
CURRENT
VOLTAGE

Reply: none

Example: NORMAL,VOLTAGE
NORMAL,CURRENT
NORMALISE,VOLTAGE
NORMALISE,CURRENT

Notes: The “normalise” function adjusts the scale factors on each current channel so that they read the same as phase 1. The reference can be either the current measured on phase 1 or if there is a reference CT it can be connected to the external input of phase 1 voltage and used as a reference.

PFCNV

PFCNV

Function: Set power factor sign convention.

Description: Fundamental power factor is given a sign depending convention either:
negative if lagging current
negative if leading current

Format: PFCNV,*type*

Arguments: *type*:
NEGLAG
NEGLEA

Reply: none

Example: PFCNV,NEGLAG

Notes: An inductive load would have a lagging current, a capacitive load would have a leading current.
The sign given to VAr can be independently set: see VARCON

PHANGREF**PHANGREF**

Function: Set phase angle reference

Description: Fourier transform analysis can be phase referred to current or voltage fundamental

Format: *PHANGREF,reference*
PHANGR,reference

Arguments: reference:
 VOLTAGE
 CURRENT

Reply: none

Example: *PHANGR,CURRENT*
PHANGREF, CURRENT

Notes: If measuring current without any voltage present it is important to set the phase angle reference to CURRENT for the fundamental to be accurate.

PHASEM**PHASEM**

Function: Set phase meter mode.

Description: Select phase meter mode and reference.

Format: PHASEM,*reference*

Arguments: *reference*:

CH1 ratio = ch2/ch1

CH2 ratio = ch1/ch2

Reply: none

Example: PHASEM,CH2

Notes:

On the instrument this is referred to as Computation in the Phase Meter menu.

PHASEM? **PHASEM?**

Function: Phase meter query

Description: Reads phase meter results.
Sets phase meter mode if not already set.
Waits for next unread data if available.
Clears new data available bit read by DAV?

Format: PHASEM?
PHASEM,*phase*?

Arguments: *phase*:
PHASE1
PHASE2
PHASE3
PHASE4
PHASE5
PHASE6
PHASES?

Reply: 5 data values separated by commas
freq,mag1,mag2,dB,phase

Example: PHASEM,CH1
PHASEM,PHASE1?
data returned

Notes: The phase convention can be set to 0° to -360°, 0° to +360°, or +180° to -180° in the SYSTEM menu or using PHCONV command.
PHASEM? without specifying the phase returns the appropriate single phase data.

PHCONV**PHCONV**

Function: Set phase convention

Description: Set phase convention

Format: PHCONV,*convention*

Arguments: *convention:*
180: -180 to +180
-360: 0 to -360
+360: 0 to +360

Reply: none

Example: PHCONV, -360

Notes: 0 to -360 degrees is usually used for power analysis applications

POWER**POWER**

Function: Set up power analyser mode.

Description: Configure power analyser with sum current display type

Format: **POWER,sum type**

Arguments: sum type:
TOTAL
AVERAGE

Reply: none

Examples: **POWER,TOTAL**

Notes:

POWER?**POWER?**

Function: Read power analyser results

Description: Reads back latest power analyser results.
Sets power analyser mode.
Waits for next unread data if necessary.
Clears new data available status bit.

Format: **POWER,*phase*,*results*?**

Arguments:

- phase*:**
 - PHASE1
 - PHASE2
 - PHASE3
 - PHASE4
 - PHASE5
 - PHASE6
 - PHASES
 - SUM
 - NEUTRAL (current only)
- results*:**
 - WATTS
 - VOLTAGE
 - CURRENT
 - VECTORS
 - RMS
 - WVA
 - PH-PH

PPA35xx communications manual

Reply:	WATTS: freq,W,W.f,VA,VA.f,VAr,VAr.f,pf,pf.f, Wdc,W.h VOLTAGE or CURRENT: freq,rms,mag,dc,phase,pk,cf,mean, form factor,harm VECTORS: freq,vmag1,vlag1,amag1,alag1..... RMS: freq,vrms1,vdc1,arms1,adc1..... WVA: freq,w1,vrms1,arms1,w2..... PH-PH: freq,rms1,mag1,lag1,rms2...
Example:	POWER,VECTORS? data returned
Notes:	POWER? without specifying the phase returns the appropriate single phase data. PHASES returns the data for all valid phases 1-3.

Function: Select only primary functions.

Description: Sets the instrument to only compute total functions not fundamentals, in order to allow shorter measurement windows.

Format: PRIMAR,*value*

Arguments: *value*:

ON

OFF

Reply: none

Example: PRIMAR,ON

Notes: When primary is on, fundamental values will be displayed as zero.

On the Instrument this command adjusts the HIGH SPEED mode option that can be found in the ACQU > Advanced menu options:

PRIMAR, ON = HIGH SPEED > ENABLED
PRIMAR, OFF = HIGH SPEED > DISABLED

PROGRA**PROGRA**

Function: Access non volatile program stores.

Description: Recall, store or delete non-volatile program store.

Format: PROGRA,*function,number*

Arguments:

function:	RECALL
	STORE
	DELETE
number	
	0-99

Reply: none

Example: PROGRA,RECALL,13

Notes: Number 0 represents factory default, which can only be recalled.

PROGRA? **PROGRA?**

Function:	Identify current program or list all stored programs.
Description:	Sending the argument FILES? – Lists all stored programs. The reply includes the location, file name and date saved for each program. Sending the argument NAME? - Displays the name of the last program to be loaded or recalled.
Format:	PROGRA
Arguments:	FILES? NAME?
Reply:	text string
Example:	PROGRA,FILES? 2,PCIS,21/11/2017 3,,21/11/2017 10,remote program,11/01/18
	PROGRA,NAME? factory default
	PROGRAM,NAME? Remote program
Notes:	If a program is stored but not given a name the return string will display no data for the name. See example above.
	Only the first six digits of the command are required so PROGRA and PROGRAM are both valid, both return the same data.

RANGE	RANGE
Function:	Set channel ranging.
Description:	Select minimum range and range control for a given input channel.
Format:	<i>RANGE,channel,ranging,range</i>
Arguments:	<p>channel: CH1 CH2 CH3 CH4 CH5 CH6</p> <p>ranging: AUTO UPAUTO MANUAL</p> <p>range: range number 1-10</p>
Reply:	none
Example:	RANGE,CH2,MANUAL,4
Notes:	CH1, CH3 & CH5 set the voltage ranges. CH2, CH4, & CH6 set the current ranges. Refer to the user manual for the range corresponding to each range number Independent Ranging needs to be enabled to adjust CH3 – CH6.

RESOLU**RESOLU**

Function: Set the data resolution

Description: Data is returned in scientific format with exponent and mantissa. The resolution of the mantissa may be selected to be 5 digit (NORMAL) or 6 digit (HIGH) or 20 bit (BINARY).

Format: RESOLU,*format*

Arguments: *format*:

NORMAL	(5 digit mantissa)
HIGH	(6 digit mantissa)
BINARY	(compressed format)

Reply: none

Example: RESOLU,HIGH

Notes: Data format for NORMAL is:
[-]1.2345E[-]00
Data format for HIGH is:
[-]1.23456E[-]00
The sign of the mantissa and exponent are only sent if negative shown as [-] in the above examples
BINAY format encodes each non-integer value in a proprietary 4 byte format for higher speed data transfer.

[Further notes on data format are included in section 1.4]

RESULT

RESULT

Function: Access results stores.

Description: Recall, store or delete results.

Format: RESULT,*function,number*

Arguments: function:

RECALL

STORE

DELETE

number

1-99

Reply: none

Example: RESULT,RECALL,13

Notes:

RESULT?

RESULT?

Function: Identify used result stores.

Description: Reads a directory of the result locations.

Format: RESULT,NAME?
RESULT,FILES?

Arguments: none

Reply: Name of last recalled result or program
List of names of all stored results

Example: RESULT,FILES?
10,AMW1,18/01/2016
11,AMW2,21/01/2016
RESULT,RECALL,11
RESULT,NAME?
AMW2

Notes:

REZERO**REZERO**

Function: Rezero front end

Description: Request the DSP to re-compensate for dc offset and compute a new autozero

Format: REZERO

Arguments: none

Reply: none

Example: REZERO

Notes:

SCALE**SCALE**

Function: Set channel scale factor.

Description: Set a multiplying scale factor for a given input channel.

Format: *SCALE,channel,factor*

Arguments:

- channel:
 - CH1
 - CH2
 - CH3
 - CH4
 - CH5
 - CH6
- factor:
 - multiplying scale factor

Reply: none

Example: SCALE,CH2,10

Notes: CH3 to CH6 only apply when Independent Ranging is enabled.

When Independent Ranging is disabled:
CH1 sets the scale for all voltage channels
CH2 sets the scale for all current channels

SCOPE?	SCOPE?
Function:	Fetch raw scope data.
Description:	Read back raw oscilloscope data.
Format:	<i>SCOPE,channel?</i> <i>SCOPE,phase,channel?</i>
Arguments:	phase: PHASE1 PHASE2 PHASE3 PHASE4 PHASE5 PHASE6 NEUTRA channel: VOLTAGE CURRENT
Reply:	252 signed integers: range trigger 250 x data
Example:	HOLD,ON SCOPE,PHASE1,VOLTAGE? read data SCOPE,PHASE2,VOLTAGE? read data SCOPE,PHASE3,VOLTAGE? read data HOLD,OFF
Notes:	Group 2 must be the active group to receive data for Phase 4 to Phase 6.

SCREEN?**SCREEN?**

Function:	Read the screen data
Description:	Returns a bit map of screen pixel display in ascii and hex format
Format:	SCREEN? SCREEN,COLOUR? SCREEN, <i>group</i> SCREEN,COLOUR, <i>group</i> ?
Arguments:	Group GROUP1 GROUP2
Reply:	Multiple lines of data bit values
Example:	SCREEN? data returned
Notes:	SCREEN? response: 272 lines of 60 bytes in ASCII coded Hex (2 characters for each byte) preceded by #H. Each byte represents 8 dots where the lsb is the leftmost dot of the display The bit is set for on and cleared for off SCREEN,COLOUR? response: 1088 lines of 120 bytes preceded by #C Each line of the display is sent as four lines of data from left to right Each byte represents a single RGB dot in binary format: 0 1 r1 r0 g1 g0 b1 b0

SHUNT **SHUNT**

Function: Set channel attenuator or shunt value

Description: For voltage channels, sets the attenuator value.
For current channels, sets the resistance factor of an external current shunt to be divided into the measured voltage for a given input channel.

Format: SHUNT,*channel,resistance*

Arguments:

- channel:
 - CH1
 - CH2
 - CH3
 - CH4
 - CH5
 - CH6
- resistance:
 - CH1: attenuator ratio
 - CH2: shunt resistance in Ohms

Reply: none

Example: SHUNT,CH1,10
SHUNT,CH2,5

Notes: CH1 sets the attenuator value for all voltage channels when independent ranging is disabled.
CH2 sets the shunt value ~~is set~~ for all current channels when independent ranging is disabled.

Independent Ranging needs to be enabled to adjust CH3 – CH6.

SMOOTH**SMOOTH**

Function: Select the smoothing

Description: Sets the filter time constant and dynamic response.

Format: SMOOTH,*type,dynamics*

Arguments:

- type:
 - NONE
 - NORMAL
 - SLOW
- dynamics:
 - AUTO
 - FIXED

Reply: none

Example: SMOOTH,NORMAL,FIXED
SMOOTH,NONE

Notes: It is not necessary to send both parameters if it is only required to set the type. Both arguments must be sent to set the dynamics.
FILTER is an alias for SMOOTH

SPEED **SPEED**

Function: Sets the measurement speed

Description: Sets the target window size for the measurement.

Format: SPEED,*value,window*

Arguments:

value:	VFAST (very fast)
	FAST
	MEDIUM
	SLOW
	VSLOW (very slow)
	WINDOW

Reply: none

Example: SPEED,SLOW
SPEED,WINDOW,0.1

Notes: The window size argument is only needed for the WINDOW option. Enter the value is seconds.
The actual window size used depends on the frequency of the signal.

PPA35xx communications manual

START

START

Function: Start datalog

Description: Initiate datalog data acquisition.

Format: START

Arguments: none

Reply: none

Example: DATALOG, RAM, 0.02
 START

Notes:

STATUS? **STATUS?**

Function: Read back channel ranging status.

Description: Read back condition of selected channel:
range number (1-16)
range text
overflow/underflow status

Format: STATUS?
or: STATUS,*channel*?

Arguments: channel:
CH1
. .
CH6

Reply: range number,range text,over/under/ok
1-8
range as per RANGE command
OVER if overflow
LOW if underflow
OK if in range

Example: STATUS,CH1?
6,300V,OK
STATUS?
OK

Notes: STATUS? gives a summary value
reporting OK only if all channels are not
overrange or underrange

STOP

STOP

Function: Stop datalog

Description: Stop datalog data acquisition.

Format: STOP

Arguments: none

Reply: none

Example: DATALOG, RAM, 0.02
 START
 wait for data values
 STOP
 read data values

Notes:

SUSPEN**SUSPEN**

Function: Suspend data acquisition.

Description: Disable the data acquisition to maximise the communication speed.

Format: SUSPEN,*value*

Arguments: *value*:

ON

OFF

Reply: none

Example: FAST,ON
SUSPEN,ON
MULTILOG?
SUSPEN,OFF
FAST,OFF

Notes: It should be remembered that the data on the screens for both groups will not be updating with data acquisition disabled.

TAGREP**TAGREP**

Function:	Set the comms reply tag
Description:	When TAGREP is enabled any reply string is preceded by an identifier string in order to identify a message from a given instrument connected to a network.
Format:	<i>TAGREP,setting</i>
Arguments:	<i>setting:</i> DISABLED or OFF ENABLED or ON
Reply:	none
Example:	*ESR? 1 TAGREP,ON *ESR? PPA3560:04656:1
	 TAGREP,ENABLE *ESR? 196-05099:1
Notes:	Using TAGREP, ON will result in a reply string preceded with the instrument type and serial number. Using TAGREP, ENABLE will result in a reply string preceded only with the instrument serial number.

TORQSP**TORQSP**

Function:	Set up torque and speed measurement
Description:	Set scaling and offset for torque and speed measurements. Pulsed input has a value for the number of pulses per revolution
Format:	<code>TORQSP,type,scale1,scale2</code> <code>TORQSP,OFFSET,offset1,offset2</code>
Arguments:	<p>type: DISABLED ANALOG PULSED (SPEED) OFFSET</p> <p>scale1 and scale 2 multiplying factor in Nm/V or rpm/V pulses/rev</p> <p>offset1 and offset2 zero level in V</p>
Reply:	None
Examples:	<code>TORQSP,PULSED,10,50</code> speed measured by pulse torque scaling = 10Nm/V 50 pulses/revolution
	<code>TORQSP,ANALOG,10,1</code>
Notes:	If type = ANALOG then speed scaling is in rpm/V, if type = PULSED then speed scaling is pulses/rev

TORQSP?**TORQSP?**

Function: Read the mechanical power, torque and speed

Description: Returns measured mechanical power value along with the torque and speed values

Format: TORQSP?

Arguments: none

Reply: 3 data values separated by commas:
power, torque, speed

Example: TORQSP?
Data returned

Notes: Mechanical power displayed in Watts
Torque displayed in Nm
Speed displayed in rpm

PPA35xx communications manual

USER? **USER?**

Function: Read the user data
Description: Returns up to 3 lines of user data
Format: USER?
Arguments: none
Reply: 3 lines of ASCII terminated by CR
Example: USER?
 Newtons4th Ltd
 R&D department
 KinetiQ #4

Notes:

VARCON**VARCON**

Function: Set VAr sign convention.

Description: Fundamental VAr measurement is given a sign depending convention either:
negative if lagging current
negative if leading current

Format: VARCON,*type*

Arguments: *type*:
NEGLAG
NEGLEA

Reply: none

Example: VARCON,NEGLAG

Notes: An inductive load would have a lagging current, a capacitive load would have a leading current.
The sign given to power factor can be independently set: see PFCONV

VERSIO?**VERSIO?**

Function:	Read the instrument code versions.
Description:	Returns an ASCII string with the details of the various parts of the instrument firmware.
Format:	VERSIO?
Arguments:	none
Reply:	date code, type, cpu, fpga, dsp, boot type: 0 – 20A 4 – 30A
Examples:	VERSIO? KQ4715,4,2.11,2.11,2.02,2.01
Notes:	This data can be displayed on the screen by pressing SYSTEM then BACK

VRMS

VRMS

Function: Set up rms voltmeter.
Description: Set mode to rms voltmeter.
Format: VRMS
Arguments: none
Reply: none
Examples: VRMS
Notes: This has the same effect as MODE,VRMS

VRMS?**VRMS?**

Function:	Read true rms voltmeter results
Description:	Reads back latest voltmeter results. Waits for next unread data if necessary. Clears new data available status bit.
Format:	<i>VRMS,phase,results?</i>
Arguments:	results: RMS MEAN SURGE phase: PHASE1 PHASE2 PHASE3 PHASE4 PHASE5 PHASE6 PHASES
Reply:	RMS: 6 data values separated by commas Vrms,Arms,Vdc,Adc,Vac,Aac MEAN: 6 data values separated by commas Vrms,Arms,Vmean,Amean,Vff,Aff SURGE: 8 data values separated by commas Vrms,Arms,Vpk,Apk,Vcf,Acf, Vsurge,Asurge
Example:	VRMS,PHASE1,RMS?
Notes:	VRMS? without specifying the phase returns the appropriate single phase data.

WIRING**WIRING**

Function: Select wiring mode.

Description: Set wiring mode for computation of SUM and neutral data.

Format: WIRING,*type*

Arguments: *type*:

- SINGLE (single ph 1)
- 2PHASE (2 ph 2 wattmeter)
- 3PH2WA (3 ph 2 wattmeter)
- 3PH3WA (3 ph 3 wattmeter)
- INDPH3 (3 ph 2 wattmeter + ph3)
- PHASE1 (single ph 1)
- PHASE2 (single ph 2)
- PHASE3 (single ph 3)

Reply: none

Examples: WIRING,PHASE2

Notes: WIRING,SINGLE is the same as
WIRING,PHASE1
Use GROUP1 command to set a single group with four or more phases.

XSCALE**XSCALE**

Function: Enables extended system calibration mode

Description: Enable External system scaling in the AUX menu. Select the required range (1 to 4) for each channel.

Format: Xscale,function,
Xscale,channel,range

Arguments: Function
Enable
Disable

Channel:
CH1
CH2
CH3
CH4
CH5
CH6

Range:
1 (1 ohm)
2 (2.5 ohm)
3 (5 ohm)
4 (10 ohm)none

Reply: none

Example: Xscale,enable

This example enables the mode.

Xscale,CH4,2

This example loads the 2.5ohm range (range 2) for phase 2 current.

PPA35xx communications manual

Notes: To use this command it is necessary to first enable the mode and then resend the command to individually set up each channel.

This command provides a multiple scaling option for the system calibration of the PPA35xx with a LEM6.

Sending this command automatically enables independent ranging.

ZERO**ZERO**

Function: Apply or remove the zero

Description: Applies or removes a zero function depending on the measurement mode (same as pressing ZERO key). Resets the integration data and timer if in power integration mode.

Format: ZERO
ZERO,DELETE

Arguments: none

Reply: none

Example: ZERO

Notes:

ZOOM**ZOOM**

Function: Sets the display zoom parameters.

Description: Sets the zoom level and data.

Format: ZOOM,*level,data1,data2,data3,data4*

Arguments:

- level:
 - 0 – normal
 - 1 – zoom data larger font (zoom level 1)
 - 2 – zoom data only (zoom level 2)
 - 3 – first three zoom data only (zoom level 3)
- data1-4:
 - zoom data
 - data consists of line number for channel 1 or line number + 64 for channel 2

Reply: None

Example: VRMS
ZOOM,1,1,65 (level 1, ch1 rms, ch2 rms)

Notes: It is not necessary to send all the parameters, but whatever parameters are sent must be in the correct order.

ZOOM?**ZOOM?**

Function: Read the display zoom parameters.

Description: Reads the zoom level and data.

Format: ZOOM?

Arguments:

Reply: 5 integers separated by commas:
level:

0 – normal

1 – zoom data larger font (zoom
level 1)

2 – zoom data only (zoom level 2)

3 – first three zoom data only (zoom
level 3)

data1-4:

zoom data

data consists of line number for channel 1
or line number + 64 for channel 2

Example: ZOOM?

1,1,65,0,0 (level 1, ch1 rms, ch2 rms)

Notes:

3 Multilog Application Guide

Configuring the N4L PPA Power Analyzer for Data logging

The Multilog (MULTIL) command provides an excellent method for data logging up to 64 parameters of information via one query command - MULTIL?

The instrument will return a comma-separated string which relates to the MULTIL,X,X,X setup commands previously entered by the relevant communication method. This enables the system to send one query and return up to 64 different parameters, from different phases in one response.

Step 1.

Reset “MULTILOG” using the **MULTIL,0** command

This will clear any previously entered Multilog parameters and ensure the instrument does not return unwanted results.

Step 2.

Set up the Multilog parameters

The format of the Multilog command is as follows

MULTILOG, Index, Phase, function

Index is the order in which the value is returned (Effectively allocating a “slot” for the parameter in the returned string)

Phase is the phase (PH1, PH2, PH3 etc) from which the result should be acquired.

PPA35xx communications manual

Phase selection:

1 = Phase 1	6 = ADI40
2 = Phase 2	7 = Phase 4
3 = Phase 3	8 = Phase 5
4 = Sum 1	9 = Phase 6
5 = Neutral	10= Sum 2

Function is the parameter type (eg. Watts, VAr, Frequency etc) of the return.

The Function ID is chosen from Appendix B which is a continually growing list due to firmware upgrades of the power analyzers at N4L, at present the PPA3500 has 99 functions:

Function	Measurement	Notes
1	frequency	
2	watts	
3	VA	
4	VAr	
5	power factor	
6	fundamental watts	
7	fundamental VA	
8	fundamental VAr	
9	fundamental PF	
10	harmonic watts	
11	harmonic watts %	
12	impedance	
13	resistance	

Example extract from the Multilog function list

Required Parameters**MULTILOG Pattern**

Order parameter to be returned within string	Phase (channel) of data returned	Parameter required
1	1	Frequency
2	1	Watts Phase 1
3	2	Watts Phase 2
4	3	Watts Phase 3
5	1	RMS Voltage Phase 1
6	2	RMS Voltage Phase 1
7	3	RMS Voltage Phase 1

Command	Index	Phase	Function
MULTIL,	1	1	1
MULTIL,	2	1	2
MULTIL,	3	2	2
MULTIL,	4	3	2
MULTIL,	5	1	50
MULTIL,	6	2	50
MULTIL,	7	3	50

Command strings to sent, reference the above Multilog pattern;

MULTIL,0 // clears Multilog

MULTIL,1,1,1 // set Frequency as parameter 1

MULTIL,2,1,2 // set Phase 1 Watts as parameter 2

MULTIL,3,2,2 // set Phase 2 Watts as parameter 3

MULTIL,4,3,2 // set Phase 3 Watts as parameter 4

MULTIL,5,1,50 // set Phase 1 RMS Voltage as parameter 5

MULTIL,6,2,50 // set Phase 2 RMS Voltage as parameter 6

MULTIL,7,3,50 // set Phase 3 RMS Voltage as parameter 7

Step 3.

Send Multil query and read return string.

MULTIL? // returns a comma separated string as

Example return string:

5.0000E1, 2.4500E2, 2.4320E2, 2.5421E2, 1.0232E3, 1.0152E3, 1.0546E3

↑ ↑ ↑ ↑ ↑ ↑ ↑
Frequency PH1 Watts PH2 Watts PH3 Watts PH1 RMS Volt PH2 RMS Volt PH3 RMS Volt

Appendix A – Configurable parameters

All parameters can be accessed using the CONFIG command:

CONFIG,number,parameter

Send GROUP,2 to access the parameters for group 2. All subsequent commands will be applied to group 2 until GROUP,1 is sent.

Note that not all parameters have a corresponding value for group 2. For example the selection of COM port is common to both groups.

<i>number</i>	<i>Function</i>	<i>parameter</i>
1	Operating mode, (sets Main Mode)	0=RMS Voltmeter 1=Phase Meter 2=Power Analyser 3=Impedance Analyser 4=Power Integrator 5=Harmonic Analyser 7=Oscilloscope
2	Resolution, (remote options – digit resolution)	0=Normal 1=High 2=Binary
4	Autozero manual or auto, (System options)	0=Auto 1=Manual
6	Phase convention, (System options)	0=-180° to +180° 1=0° to -360° 2=0° to +360°

PPA35xx communications manual

- 7 Frequency lock on/off, (Acquisition advance options)
0=Normal
1=Constant
2=Dynamic
- 9 Keyboard beep on/off, (System options)
0=Off
1=On
- 10 Ignore overload,(Acquisition advance options)
0=Off
1=On
- 11 Low frequency mode, (Acquisition control)
0=Off
1=On
- 12 Window size, (Acquisition control, speed-window - Enter figures in seconds)
- 13 Speed, (Acquisition control or Phase meter)
0=Very Slow
1=Slow
2=Medium
3=Fast
4=Very Fast
5=Window
- 14 Smoothing (Acquisition Control or Phase Meter)
0=Normal
1=Slow
2=None
- 15 Smoothing Response (Acquisition Control or Phase meter)
0=Auto reset
1=Fixed time
- 16 Baud rate, (Remote options , RS232)
0=38400
1=19200
2=9600
3=1200

PPA35xx communications manual

- 18 LAN IP address nibble 3, (Remote options - LAN - enter figure as required)
- 19 LAN IP address nibble 2, (Remote options - LAN - enter figure as required)
- 20 LAN IP address nibble 1, (Remote options - LAN - enter figure as required)
- 21 LAN IP address nibble 0, (Remote options - LAN - enter figure as required)
- 22 Independent ranging, (Range options)
 - 0=Disabled
 - 1=Enabled
- 23 Grouping (PPA3560), (ACQU options)
 - 1=1+2+3 : 1+2+3
 - 2=1+2+3 : 4+5+6
 - 3=1+2+3+4
 - 4=1+2+3+4+5
 - 5=1+2+3+4+5+6
- 24 Enable channel 1, (Range – voltage input)
 - 1=Internal
 - 3=External Attenuator
- 25 Enable channel 2, (Range – current input)
 - 1=Internal
 - 2=External Shunt
- 26 Input range channel 1, (Range – minimum range voltage)
 - 0=100mV
 - 1=300mV
 - 2=1V
 - 3=3V
 - 4=10V
 - 5=30V
 - 6=100V
 - 7=300V
 - 8=1kV
 - 9=3kV

PPA35xx communications manual

- 27 Input range channel 2, (Range – minimum range current)
0=30mA
1=100mA
2=300mA
3=1A
4=3A
5=10A
6=30A
7=100A
8=300A
9=1kA
- 28 Input ranging channel 1, (Range – autoranging voltage)
0=Full Autorange
1=Range up only
2=Manual
- 29 Input ranging channel 2, (Range – autoranging current)
0=Full Autorange
1=Range up only
2=Manual
- 30 Coupling, (Coupling)
0=ac+dc
1=ac
2=dc
- 31 Bandwidth, (Coupling)
0=Wide(dc-1MHz)
1=Low (dc-200kHz)
- 32 Scale factor channel 1 voltage, (Ranging - Enter figures as required)
- 33 Scale factor channel 2 current, (Ranging - Enter figures as required)
- 34 External attenuator channel 1, (Ranging – voltage input - attenuator ratio
– Enter figures as required)
- 35 External shunt channel 2, (Ranging – current input - resistance value
– Enter figures as required)
- 36 Phase 1 noise filter, (Coupling)
0 = Off
1 = On

PPA35xx communications manual

- 37 Phase 1 noise filter frequency, (Coupling, enter frequency in Hertz)
- 38 Frequency reference voltage/current, (Acquisition control)
0=Voltage
1=Current
- 40 Frequency reference phase, (Acquisition control)
0=Phase 1
1=Phase 2
2=Phase 3
- 41 Display page, (Main display)
0=Phase 1 page
1=Phase 2 page
2=Phase 3 page
3=Sum page
4=Phase 1,2 & 3 page
5=Phase 1,2 & 3 fundamentals page
6=NEU page
- 42 Zoom level, (Main display)
0=Zoom level 0
1=Zoom level 1
2=Zoom level 2 – 4 figures
3=Zoom level 3 – 3 figures
- 47 Datalog display type, (Datalog display information mode)
0=Real Time
1=Table
2=Graph
- 48 Manual frequency, (Acqu advanced options – frequency in Hertz)
- 49 DFT selectivity, (Acqu advance options)
0=Normal
1=Narrow
- 50 Program 1-4 direct load, (System options)
0=Disabled
1=Enabled

PPA35xx communications manual

- 51 **Language,** (System options)
 0=English
 1=Other language if installed
- 52 **Frequency filter,** (Acquisition control)
 0=Disabled
 1=Enabled, fundamental>1kHz
 2=Enabled, fundamental<1kHz
- 53 **Phase reference,** (Acquisition control)
 0=Voltage
 1=Current
- 58 **Datalog memory type,** (Datalog)
 0=Disabled
 1=RAM
 2=Internal
 3=USB Memory stick
- 59 **Datalog Interval,** (Datalog) (Enter interval time figure in seconds)
- 60 **Datalog graph,** (Datalog-RAM)
 0=Together
 1=Separate
- 61 **Formula,** (Maths)
 0=Disabled
 1=(term1 + term2/term3 + term4)
 2=(term1 + term2) x term3/term4
 3=term1 x term2/(term3 + term4)
 4=(term1 + term2 + term3)/term4
- 62 **Argument term 1**
 0=Disabled
 1=Constant
 2=Voltage
 3=Current
 6=Frequency
 7=Power

PPA35xx communications manual

- 63 Sub argument term 1, (For voltage and current arguments only)
0=rms
1=dc
2=ac
3=Fundamental
4=Peak
5=Mean
6= Ph-Ph rms
7=Ph-Ph mag
- 64 Term 1 coefficient, (Enter value)
- 65 Argument term 2,
0=Disabled
1=Constant
2=Voltage
3=Current
6=Frequency
7=Power
- 66 Sub argument term 2, (For voltage and current arguments only)
0=rms
1=dc
2=ac
3=Fundamental
4=Peak
5=Mean
6= Ph-Ph rms
7=Ph-Ph mag
- 67 Term 2 coefficient, (Enter value)
- 69 Low frequency mode minimum frequency, (Enter value)
- 70 Application mode,
0=Normal
1=PWM
2=Lighting ballast
3=Inrush current
4=Transformer mode
5=Standby power
6=Calibration mode

PPA35xx communications manual

- 71 **PWM Frequency filter,** (Application options mode – PWM motor drive)
 0=4kHz
 1=1kHz
 2=250Hz
 3=64Hz
 4=250kHz
 5=64kHz
 6=16kHz
- 72 **Frequency tracking speed,** (Application options mode - Lighting Ballast)
 0=Fixed time
 1=Fast
 2=Medium
 3=Slow
- 73 **PWM low frequency,** (Application options mode)
 0=Off
 1=On
- 74 **Argument term 3**
 0=Disabled
 1=Constant
 2=Voltage
 3=Current
 6=Frequency
 7=Power
- 75 **Sub argument term 3,** (For voltage and current arguments only)
 0=rms
 1=dc
 2=ac
 3=Fundamental
 4=Peak
 5=Mean
 6= Ph-Ph rms
 7=Ph-Ph mag
- 76 **Term 3 coefficient,** (Enter value)

- 77 Argument term 4
0=Disabled
1=Constant
2=Voltage
3=Current
6=Frequency
7=Power
- 78 Sub argument term 4, (For voltage and current arguments only)
0=rms
1=dc
2=ac
3=Fundamental
4=Peak
5=Mean
6= Ph-Ph rms
7=Ph-Ph mag
- 79 Term 4 coefficient, (Enter value)
- 82 Wiring configuration, (Acquisition control)
0=Single phase 1
1=2 phase 2 wattmeter
2=3 phase 2 wattmeter
3=3 phase 3 wattmeter
4=Single phase 2
5=Single phase 3
6=3 phase 2 wattmeter + PH3
- 83 Integration, (Mode - Power integrator)
0=Signed
1=Magnitude
- 84 Torque + speed, (Application options – PWM motor drive)
0=Disabled
1=Analogue speed
2=Pulsed speed
3=Pulsed Torque
4=Pulsed
- 85 Torque scaling Nm/V, (Applications – PWM motor drive) (Also transformer scale factor Deg/v)(Enter Nm/v value)

PPA35xx communications manual

- 86 Speed scaling RPM/V,(Applications – PWM motor drive)(Enter rpm/v value)
- 87 Pulses per revolution,(Applications-PWM motor drive)(Enter pulses/rev value)
- 88 Integration display, (Mode - Power integrator)
0=Total
1=Average
- 89 Sum current average, (Power analyzer)
0=Total
1=Average
- 90 Input compensation, (Mode)
0=Disabled
1=Enabled
- 91 Power factor sign, (Power analyzer)
0=Negative lagging
1=Negative leading
- 92 VAr sign, (Power analyzer)
0=Negative lagging
1=Negative leading
- 93 Efficiency computation, (Power analyzer)
0=Disabled
1=Phase / next
2=Next / Phase
3=group2/group
4=group1/group2
5=mechanical/sum
6=sum/mechanical
7=Phase 3/Sum
8=Sum/Phase 3
- 94 Torque offset, (Mode – value in Volts)
- 95 Speed offset, (Mode – value in Volts)

PPA35xx communications manual

- 97 Equipment (Voltage) rating for Harmonic Factor,
(Harmonic mode – value in Volts)
- 99 Computation mode, (Harmonic analyzer)
0=Difference formula
1=Harmonic series
2=TIF
3=THF
4=TRD
5=TDD
6=Series harmonic phase
7=Difference formula
8=Harmonic RMS
9=Harmonic factor
- 100 Selected harmonic, (Harmonic analyzer - figure = harmonic required)
- 101 Harmonic series up to, (Harmonic analyzer - figure = harmonic max)
- 102 Voltage bargraph scale, (Harmonic analyzer - figure = % required)
- 103 Equipment (Current) rating (TRD / Harmonic Factor),
(Harmonic analyzer – TRD / Harmonic factor modes – enter figure)
- 104 Current bargraph scale, (Harmonic analyzer - figure = % required)
- 106 Timebase, (Scope - Enter figure/div)
- 107 trigger level, (Scope - Enter figure/div)
- 108 Pretrigger, (Scope)
0=None
1=25%
2=50%
3=75%
- 109 trigger polarity, (Scope)
0=Rising edge
1=Falling edge

PPA35xx communications manual

- 110 trigger Mode, (Scope)
0=Auto
1=Normal
2=Single shot
- 111 trigger reference, (Scope)
0=Voltage
1=Current
- 113 cursors enable, (Scope)
0=Off
1=On
- 114 trigger HF reject, (Scope)
0=Off
1=On
- 115 Trace, (Scope)
0=Dual
1=Voltage
2=Current
3=Together
- 117 DFT phase angle ref, (System)
0=Cosine
1=Sine
- 119 Zoom 2 high resolution, (System)
0=Disabled
1=Enabled
- 120 Brightness, (System)
0=Low
1=High
- 122 Auxiliary device, (Aux control)
0=None
6=PCIS
10=ADI40-4
11=ADI40-8
12=ADI40-12
13=ADI40-16

PPA35xx communications manual

- 128 **Switch phase offset,** (Aux control – PCIS device)
 0=0°
 1=45°
 2=90°
 3=135°
 4=180°
 5=225°
 6=270°
 7=315°
- 129 **Switch on cycles,** (Aux control – PCIS device)
 0=Single cycle
 1=Continuous
 2=Half cycle
- 131 **Sum VA & VAr computation,** (Power Analyser)
 0=Low distortion
 1=High Distortion
- 132 **Integrator-run time** (Hours), (Mode – Power integrator - enter figure)
- 133 **Integrator-Run time** (mins), (Mode - Power integrator – enter figure)
- 134 **Ph – Ph Measurement (Conversion),** (Power analyser)
 0=rms
 1=Mean
 2=star-delta
 3=delta-star
- 135 **Difference THD,** (Power analyser – penultimate line - Vthd)
 0=Disabled
 1=Enabled including dc
 2=Enabled excluding dc
- 137 **Parameter,** (Impedance analyzer)
 0=Auto
 1=Capacitance
 2=Inductance
 3=Impedance

PPA35xx communications manual

138 **Measurement,** (Impedance analyzer)
 0=Series
 1=Parallel

139 **Phase offset,** (Impedance analyzer - Enter figures)

140 **Voltage peak,** (rms voltmeter)
 0=Signed
 1=Separate
 2=Unfiltered

143 **Last Line,** (rms voltmeter)
 0=Disabled
 1=Crest Factor
 2=Form Factor
 3=Maths Function

144 **Rectified mean,** (rms voltmeter)
 0=Absolute
 1=Normalised

150 **Computation,** (Phase meter)
 0=ch2/ch1
 1=ch1/ch2

152 **RS232 printer enable,** (Remote options)
 0=Disabled
 1=USB memory stick
 2=RS232 (DPU-414)
 3=RS232 (DPU-D2)

153 **GPIB IEEE Address(1-30),** (Remote options)

154 **Interface,** (Remote options)
 0=RS232
 1=USB
 2=LAN
 3=GPIB

PPA35xx communications manual

- 155 Recall with program, (Remote options)
0=Off
1=On
- 156 Alarm 1 data, (Alarm options)
0=Zoom1
1=Zoom 2
2=Zoom3
3=Zoom 4
- 157 Alarm 1 type, (Alarm options)
0=Disabled
1=Linear
2=Alarm if high
3=Alarm if low
4=Outside window
5=Inside window
- 158 Alarm 1 high threshold, (Alarm options – alarm if high – enter figure)
- 159 Alarm 1 low threshold, (Alarm options – alarm if low – enter figure)
- 160 Alarm latch, (Alarm options – alarm if high)
0=Off
1=On
- 161 Alarm sounder, (Alarm options – alarm if high)
0=Enabled
1=Disabled
- 167 Alarm 2 data, (Alarm options)
0=Zoom1
1=Zoom 2
2=Zoom 3
3=Zoom 4
- 168 Alarm 2 type, (Alarm options)
0=Disabled
2=Alarm if high
3=Alarm if low
4=Outside window
5=Inside window

PPA35xx communications manual

- 169 Alarm 2 high threshold, (Alarm options – alarm if high – enter figure)
- 170 Alarm 2 low threshold, (Alarm options – alarm if low – enter figure)
- 176 Enable channel 3, (Range–voltage input)(Range - independent ranging enabled)
 1=Internal
 3=External Attenuator
- 177 Enable channel 4, (Range – current input)(Range - independent ranging)
 enabled)
 1=Internal
 2=External Shunt
- 178 Input range channel 3, (Range – minimum range voltage)
 (Range - independent ranging enabled)
 0=100mV
 1=300mV
 2=1V
 3=3V
 4=10V
 5=30V
 6=100V
 7=300V
 8=1kV
 9=3kV
- 179 Input range channel 4, (Range – minimum range current)
 (Range - independent ranging enabled)
 0=30mA
 1=100mA
 2=300mA
 3=1A
 4=3A
 5=10A
 6=30A
 7=100A
 8=300A
 9=1kAA
- 180 Input ranging channel 3, (Range – autoranging voltage) (Range
 independent ranging enabled)
 0=Full Autorange
 1=Range up only
 2=Manual

PPA35xx communications manual

- 181 Input ranging channel 4, (Range – autoranging current) (Range independent ranging enabled)
0= Full Autorange
1=Range up only
2=Manual
- 182 Coupling phase 2, (Coupling) (independent input control enabled)
0=ac +dc
1=ac
2=dc
- 184 Scale factor channel 3 voltage, (Ranging - Enter figures as required)
(Range - independent ranging enabled)
- 185 Scale factor channel 4 current, (Ranging - Enter figures as required)
(Range - independent ranging enabled)
- 186 External attenuator channel 3,(Ranging – voltage input - attenuator ratio -Enter figures as required)(Range - independent ranging enabled)
- 187 External shunt channel 4, (Ranging – current input – resistance value Enter figures as required) (Range - independent ranging enabled)
- 188 Phase 2 noise filter, (Coupling)(Independent input control –phase 2 selected)
0 = Off
1 = On
- 196 ID tag prepends comms replies
0 = Off
1 = On
- 197 High speed mode
0 = Disabled
1 = Enabled
- 200 Enable channel 5, (Range – voltage input) (Range – independent ranging enabled)
1=Internal
3=External Attenuator
5=Torque
- 201 Enable channel 6, (Range – current input) (Range - independent ranging enabled)
1=Internal
2=External Shunt

PPA35xx communications manual

- 202 Input range channel 5, (Range – minimum range voltage) (Range - independent ranging enabled)
- 0=100mV
1=300mV
2=1V
3=3V
4=10V
5=30V
6=100V
7=300V
8=1kV
9=3kV
- 203 Input range channel 6, (Range – minimum range current) (Range - independent ranging enabled)
- 0=30mA
1=100mA
2=300mA
3=1A
4=3A
5=10A
6=30A
7=100A
8=300A
9=1kA
- 204 Input ranging channel 5, (Range – autoranging voltage) (Range independent ranging enabled)
- 0=Full Autorange
1=Range up only
2=Manual
- 205 Input ranging channel 6, (Range – autoranging current) (Range – independent ranging enabled)
- 0= Full Autorange
1=Range up only
2=Manual
- 206 Coupling phase 3, (Coupling -independent input control enabled)
- 0=ac +dc
1=ac
2=dc

PPA35xx communications manual

- 208 Scale factor channel 5 voltage,(Ranging - Enter figures as required)
(Range - independent ranging enabled)
- 209 Scale factor channel 6 current, (Ranging - Enter figures as required)
(Range - independent ranging enabled)
- 210 External attenuator channel 5,(Ranging – voltage input - attenuator ratio
as required) (Range - independent ranging enabled)
- 211 External shunt channel 6, (Ranging – current input – resistance value
as required) (Range - independent ranging enabled)
- 212 Phase 3 noise filter, (Coupling)(Independent input control –phase 3 selected)
0 = Off
1 = On
- 231 Memory, (Program)
0=Internal
1=USB Memory stick
- 232 Data, (Program)
0=Program
1=Results
2=Datalog
- 233 Action, (Program)
0=Recall
1=Store
2=Delete
- 234 Location, (Program - Enter figures as required)
- 240 set clock (hrs) (System clock)
- 241 set clock (mins) (System clock)
- 242 set clock (secs) (System clock)
- 243 set date (day) (System clock)
- 244 set date (month) (System clock)
- 245 set clock (year) (System clock)

Appendix B – MULTIL parameters

function	measurement	notes
1	frequency	
2	watts	
3	VA	
4	VAr	
5	power factor	
6	fundamental watts	
7	fundamental VA	
8	fundamental VAr	
9	fundamental PF	
10	harmonic watts	
11	harmonic watts %	
12	impedance	Imp meter mode
13	resistance	Imp meter mode
14	reactance	Imp meter mode
15	impedance phase	Imp meter mode
16	efficiency	
17	fundamental efficiency	
18	maths	
19	integrated watts	integrator mode
20	integrated VA	integrator mode
21	integrated VAr	integrator mode
22	integrated rms current	integrator mode
23	average power factor	integrator mode
24	integrated fundamental watts	integrator mode
25	integrated fundamental VA	integrator mode
26	integrated fundamental VAr	integrator mode
27	integrated fundamental current	integrator mode
28	average fundamental power factor	integrator mode
29	average integrated watts	integrator mode
30	average integrated VA	integrator mode
31	average integrated VAr	integrator mode
32	average integrated fundamental watts	integrator mode
33	average integrated fundamental VA	integrator mode
34	average integrated fundamental VAr	integrator mode
35	average rms voltage	integrator mode
36	average fundamental voltage	integrator mode
37	Standby mode frequency	
38	DC watts	
39	average rms current	integrator mode

PPA35xx communications manual

40	average fundamental current	integrator mode
41	delta watts	
42	fundamental delta watts	
43	elapsed time	integrator mode
44	LCR resistance	Imp meter mode
45	LCR inductance	Imp meter mode
46	LCR capacitance	Imp meter mode
47	LCR tan delta	Imp meter mode
48	Q factor – see notes	Imp meter mode
48	k-factor – see notes	Transformer mode
49	Corrected Power	Transformer mode
50	rms voltage	
51	rms current	
52	fundamental voltage	
53	fundamental current	
54	voltage phase	
55	current phase	
56	harmonic voltage	
57	harmonic current	
58	dc voltage	
59	dc current	
60	ac voltage	
61	ac current	
62	peak voltage	
63	peak current	
64	voltage crest factor	
65	current crest factor	
66	rectified mean voltage	
67	rectified mean current	
68	voltage form factor	
69	current form factor	
70	voltage harmonic	harmonic mode
71	current harmonic	harmonic mode
72	voltage harmonic percentage	harmonic mode
73	current harmonic percentage	harmonic mode
74	voltage thd	harmonic mode
75	current thd	harmonic mode
76	voltage tif	harmonic mode
77	current tif	harmonic mode
78	phase to phase rms voltage	
79	phase to phase fundamental voltage	
80	phase to phase voltage phase angle	
81	phase to phase rms voltage	

PPA35xx communications manual

82	voltage surge	
83	current surge	
84	voltage rms deviation	transformer mode
85	voltage fundamental deviation	transformer mode
86	voltage phase deviation	transformer mode
87	voltage positive peak	
88	current positive peak	
89	voltage negative peak	
90	current negative peak	
91	voltage positive peak unfiltered	
92	current positive peak unfiltered	
93	voltage negative peak unfiltered	
94	current negative peak unfiltered	
95	In-phase component of voltage	
96	Quadrature component of voltage	
97	In-phase component of current	
98	Quadrature component of current	
99	reserved for future expansion	

Notes:

Functions 78 and 81 are the same.

Function 48 is used to measure Q-factor in Impedance meter mode AND measure Corrected Power in Transformer mode.

Phase selection:

1 = Phase 1	6 = ADI40
2 = Phase 2	7 = Phase 4
3 = Phase 3	8 = Phase 5
4 = Sum 1	9 = Phase 6
5 = Neutral	10= Sum 2

There are some special functions:

Measurement (function)	phase	Previous function
mechanical speed in Hz	neutral	dc voltage (function 58)
mechanical speed in rpm	neutral	ac voltage (function 60)
torque in Nm	neutral	rms voltage (function 50)
mechanical power	neutral	Watts (function 2)

Notes:

PPA35xx communications manual

These special functions must use the Neutral Phase (Phase 5)

Due to the limited number of function numbers available these Special functions re-use function numbers that apply to other measurements for Phases 1 to 3.

Examples for setting up individual special function measurements:

> multil,0	Setting to clear any previous data
> multil,1,5,58	Setting for Mechanical speed in Hz
> multil,1,5,60	Setting for Mechanical speed in rpm
> multil,1,5,50	Setting for Torque in Nm
> multil,1,5,2	Setting for Mechanical Power in nW
> multil?	Setting to read back and display data

Example script to return results for Mechanical Power, Torque & Speed (in rpm):

```
>  
>  
> multil,0  
> multil,1,5,2  
> multil,2,5,50  
> multil,3,5,60  
> multil?  
-1.8846E-7,-2.0984E-3,8.5765E-4
```

Newtons4th Ltd. contact details

Please direct all queries or comments regarding the PPA35xx instruments or this manual to:

Newtons4th Ltd.
1 Bede Island Road
Leicester
LE2 7EA
United Kingdom

Tel: (0116) 230 1066 international +44 116 230 1066
Fax: (0116) 230 1061 international +44 116 230 1061

E-mail address: sales@newtons4th.com
 office@newtons4th.com

web site: www.newtons4th.com

At Newtons4th Ltd. we have a policy of continuous product improvement and are always keen to hear comments, whether favourable or unfavourable, from users of our products. Please telephone, fax, write or e-mail with your comments.